

aspire® Cleito 120 Pro User Manual

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with e-liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the age of 18 years, pregnant or breast feeding women and those experiencing general ill health.



Contents:

- 1* Cleito 120 Pro tank
- 2* Coils (1*0.16Ω & 1*0.15Ω Mesh Coil)
- 1* Glass tube
- 6* O-rings
- 1* User manual
- 1* Warranty card

Cleito 120 Pro tank features

- Super easy top fill
- 3ml capacity
- Bottom adjustable airflow
- Coil resistance: 0.16Ω
- Super efficient wicking
- Massive vapor and flavor production
- Diameter: 25mm
- Length (including mouth piece): 51.5mm

Cleito 120 Pro tank filling

1. Pull to release the top metal ring
2. Add your preferred e-liquid through the top side filling slot
3. Replace the top metal ring (Push the metal ring down firmly)

1



The filling hole is located above the three dots on the tank, to prevent leaking ensure that when sliding up the top ring to fill that the dots are uppermost.



- When using a new atomizer, let the tank stand for 5 minutes after filling so the cotton can be saturated with e liquid before use.
- Do not let the tank become completely empty. Refill the tank to avoid dry burning or damage to the atomizer.

Cleito Pro Coil installation

1. Unscrew to remove the drip tip.
2. Pull to remove the top hardware.
3. Unscrew and detach the used coil.
4. Screw a new coil into the base hardware.
5. Attach the top hardware and drip tip back to the tank.

2



IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

WARNINGS AND PRECAUTIONS

Nicotine containing e-liquids are not recommended for:

- Non-smokers
- Young people under the age of 18 years;
- Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;

3

- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
- Those who have an overactive thyroid gland or have a pheochromocytoma (a tumour of the adrenal gland that can affect high blood pressure);
- Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication;
- Theophylline (to treat breathing problems)
- Ropinirole (to treat restless leg syndrome)
- Clozapine (to treat schizophrenia)

POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much you may experience one or more of the following effects:

- Feeling faint;
- Nausea (feeling sick)
- Headache
- Coughing
- Irritation of the mouth or throat
- Dizziness
- Stomach discomfort
- Hiccups

4

- Nasal congestion
- Vomiting (being sick)
- Heart palpitations
- Abnormal heart rate

If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

To learn more about your products and how to use, please visit: www.aspirecig.com

Shenzhen Eigate Technology Co., Ltd.

Building 3, Xinhongtai Industrial Park, 14 Jian'an Rd, Tangwei, Fuyong Town, Bao'an District, Shenzhen, China
Tel: +86-755-81499783 Email: service@aspirecig.com

Manufactured By Eigate MADE IN CHINA



5